

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>ALT</b>	Alternate Method	Procedure	Reported value was obtained using an alternate analytic method. Validity of reported value may be compromised	Information about the alternate analytic method used should be provided in the Exception to Method Text	Lab, QC
<b>B5D</b>	Below 5 Times MDL	Other	Reported value is greater than the method detection limit but less than 5 times the method detection limit. Validity of reported value and associated precision statistics (e.g., RPD) may be compromised		Lab, QC
<b>BAC</b>	Correction Factor, background	Corrected	Reported value was corrected for variable background contribution to the instrument signal in the determination of trace elements	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>BDL</b>	Detection Limit, less than	Limit	Analyte produced an instrument response but reported value is below a detection limit. The type of detection limit was unspecified. Validity of reported value may be compromised		Lab, QC
<b>BLQ</b>	Between Instrument Detection and Quantification	Limit	Reported value is above calculated instrument detection limit but below quantification limit. Validity of reported value may be compromised	Information about limits should be provided in the Project QA/QC Summary	Lab, QC
<b>CAJ</b>	Correction Factor, lab	Corrected	Reported value was corrected by a lab performance check factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>CAN</b>	No Result Reported, analysis canceled	No Result Reported	Analysis was canceled and not performed. No result value was reported	The reason for cancellation should be provided in the Exception to Method Text	Lab, QC
<b>CBC</b>	No Result Reported, cannot be calculated	No Result Reported	Result should have been a calculated value but it could not be determined because an operand value was qualified. No result value was reported		Lab, QC
<b>CBL</b>	Correction Factor, blank	Corrected	Reported value was corrected by a blank correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>CCA</b>	Correction Factor, calibration	Corrected	Reported value was corrected by a calibration correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>CDI</b>	Correction Factor, dilution	Corrected	Reported value was corrected by a dilution correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>CLC</b>	Correction Factor, other	Corrected	Reported value was corrected. Correction factor was derived by unspecified means or means other than those presented in this list	The value of the correction factor, if known, should be provided in the Correction Factor table. Information about how the correction factor was derived should be provided in the Result Description	Lab, QC
<b>CON</b>	Value Confirmed	Other	Reported value was confirmed by using an auxiliary analytical technique	Information about confirmation technique should be provided in the Analytic Method or the Exception to Method Text	Lab, QC
<b>CSP</b>	Correction Factor, standard pressure	Corrected	Reported value was corrected by a standard pressure correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>CST</b>	Correction Factor, standard temperature	Corrected	Reported value was corrected by a standard temperature correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>CSU</b>	Correction Factor, surrogate	Corrected	Reported value was corrected by a surrogate correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>CTP</b>	Correction Factor, standard temperature and pressure	Corrected	Reported value was corrected by a standard temperature and pressure correction factor	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>DDL</b>	Daily Detection Limit, less than	Limit	Analyte produced an instrument response but reported value is below the calculated daily detection limit. Validity of reported value may be compromised	Information about detection limits should be provided in the Project QA/QC Summary	Lab, QC
<b>EER</b>	No Result Reported, entry error	No Result Reported	Original value is known to be incorrect due to a data entry error. The correct value could not be determined. No result value was reported		Lab, QC
<b>EHT</b>	Exceeded Holding Time	Handling	Sample or extract was held longer than the approved amount of time before analysis. Validity of reported value may be compromised	The length of time that the sample was held should be provided in the Exception to Method Text	Lab, QC
<b>EST</b>	Estimated Value, outside limit of precision	Estimated Value	Reported value was not within expected limits of precision and is therefore considered an estimate		Lab, QC
<b>FAC</b>	No Result Reported, field accident	No Result Reported	Analysis was halted because a field accident either destroyed the sample or rendered it not suitable for analysis. No result value was reported	Information about the field accident should be provided in the Exception to Method Text	Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>FBB</b>	Field Bottle Blank, failed	QC Failed	A field bottle blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FBS</b>	Blank Sample, failed	QC Failed	A blank sample associated with this analysis failed the acceptance criteria. It is unknown whether the blank that failed was a field blank or a lab blank. Validity of reported value may be compromised		Lab, QC
<b>FCB</b>	Lab Calibration Blank, failed	QC Failed	A lab calibration blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FCC</b>	Continuing Calibration Check, failed	QC Setup	A continuing calibration check associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FCL</b>	Lab Control Solution, failed	QC Failed	A lab control solution associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FCN</b>	Calibration Sample, failed	QC Failed	A calibration sample (type unknown or unspecified) associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FCS</b>	Field Control Solution, failed	QC Failed	A field control solution associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FCV</b>	Coefficient of Variation Limit, failed	Other	Precision, measured as CV between multiple analyses of a sample within and between instrumental analysis runs, did not meet the method criteria. Validity of reported value may be compromised		Lab, QC
<b>FDB</b>	Dry Blank, failed	QC Failed	A dry blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FDC</b>	Drift Check, failed	QC Setup	A drift check associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FDL</b>	Lab Duplicate, failed	QC Failed	A lab duplicate associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>FFB</b>	Field Matrix Blank, failed	QC Failed	A field matrix blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FFD</b>	Field Duplicate, failed	QC Failed	A field duplicate associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FFR</b>	Field Blank, failed	QC Failed	A field blank sample (type unknown or unspecified) associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FFS</b>	Field Spike, failed	QC Failed	A field spike associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FFT</b>	Trip Blank, failed	QC Failed	A trip blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FIB</b>	Field Instrument Blank, failed	QC Failed	A field instrument blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FIC</b>	Lab Interference Check Sample, failed	QC Failed	A lab interference check sample associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised.		Lab, QC
<b>FIS</b>	Internal Standard, failed	QC Failed	An internal standard associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FKB</b>	Continuing Check Blank, failed	QC Failed	A continuing check blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FLA</b>	Field Lab Anomaly	Other	Reported value for lab measurement was inconsistent with reported value for corresponding field measurement. Validity of reported value may be compromised		Lab, QC
<b>FLB</b>	Lab Matrix Blank, failed	QC Failed	A lab matrix blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>FLC</b>	Linearity Check, failed	QC Setup	A linearity check associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FLR</b>	Lab Blank, failed	QC Failed	A lab blank sample (type unknown or unspecified) associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FLS</b>	Lab Spike, failed	QC Failed	A lab spike associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FMB</b>	Matrix Spike Blank, failed	QC Failed	A matrix spike blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FMS</b>	Matrix Spike, failed	QC Failed	A matrix spike associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FNB</b>	Lab Instrument Blank, failed	QC Failed	A lab instrument blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FOB</b>	Field Fortified Blank, failed	QC Failed	A field fortified blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FPB</b>	Lab Procedural Blank, failed	QC Failed	A lab procedural blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FPC</b>	Performance Check, failed	QC Failed	A lab performance check sample associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FPS</b>	Lab Procedural Spike, failed	QC Failed	A lab procedural spike associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FQC</b>	Quality Control, failed	QC Failed	Quality control criteria were exceeded during analysis. Value was not rejected, however. Validity of reported value may be compromised		Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>FRB</b>	Field Reagent Blank, failed	QC Failed	A field reagent blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FRF</b>	Reference material, failed	QC Failed	A reference sample (type unknown or unspecified) associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FRM</b>	Field Reference Material, failed	QC Failed	A field reference material associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FRN</b>	Lab Reagent Blank, failed	QC Failed	A lab reagent blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FRS</b>	Lab Reference, failed	QC Failed	A lab reference associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSB</b>	Lab Solvent Blank, failed	QC Failed	A lab solvent blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSD</b>	Lab Spike Duplicate, failed	QC Failed	A spiked lab duplicate associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSF</b>	Surrogate Spike, failed	QC Failed	Surrogate spike recoveries associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSK</b>	Spike sample, failed	QC Failed	A spike sample (type unknown or unspecified) associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSL</b>	Lab Spike Blank, failed	QC Failed	A spiked lab blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSP</b>	Lab Solvent Spike, failed	QC Failed	A lab solvent spike associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>FSR</b>	Standard Reference Material, failed	QC Failed	A standard reference material associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FSS</b>	Surrogate, failed	QC Failed	Surrogate recoveries associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FTB</b>	Field Filter Blank, failed	QC Failed	A field filter blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FUB</b>	Field Tubing Blank, failed	QC Failed	A field tubing blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FVS</b>	Lab Calibration Verification Solution, failed	QC Setup	A lab calibration verification solution associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>FWB</b>	Field Source Water Blank, failed	QC Failed	A field source water blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC
<b>GTL</b>	Operating Range, greater than	Limit	Reported value is above the valid operating range of the analytical system, quantitative process, or qualitative process, or reported value is above the highest calibration standard. Validity of reported value may be		Lab, QC
<b>HIB</b>	Likely Biased High	Other	Reported value is probably biased high as evidenced by LMS (matrix spike, lab) results, SRM (reference material, standard) recovery, blank contamination or other internal lab QC data. Reported value is not		QC
<b>IDL</b>	Instrument Detection Limit, less than	Limit	Analyte produced an instrument response but reported value is below the calculated instrument detection limit. Validity of reported value may be compromised	Information about detection limits should be provided in the Project QA/QC Summary	Lab, QC
<b>IDS</b>	Analyte Not Confirmed	Other	Identity of analyte could not be confirmed using an alternate technique		Lab, QC
<b>INT</b>	Interference Suspected	Other	Reported value is believed to be the result of interference and not presence of the analyte. Validity of reported value may be compromised		Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<u>Code</u>	<u>Name</u>	<u>Group</u>	<u>Description</u>	<u>Reporting Instruction Description</u>	<u>Assignor</u>
<b>INV</b>	Invalid	Other	Reported value is deemed invalid by the QC Coordinator		QC
<b>ISC</b>	Correction Factor, internal standard	Corrected	Reported value was corrected for the internal standard recovery	The value of the correction factor, if known, should be provided in the Correction Factor table	Lab, QC
<b>ISP</b>	Improper Sample Preservation	Handling	Sample was not properly preserved. Validity of reported value may be compromised		Lab, QC
<b>JCN</b>	Sample Container Damaged, no sample lost	Handling	Sample container (jar, test tube, etc.) was damaged but no portion of the sample was lost. Validity of reported value may be compromised		Lab, QC
<b>JCW</b>	Sample Container Damaged, sample lost	Handling	Sample container (jar, test tube, etc.) was damaged. At least a portion of the sample was lost. Validity of reported value may be compromised		Lab, QC
<b>KCA</b>	Known Contamination, lab analysis	Contamination	Contamination is known to have occurred during the laboratory analysis process. Validity of reported value may be compromised	The source of contamination, if known, should be provided in the Exception to Method Text	Lab, QC
<b>KCF</b>	Known Contamination, field	Contamination	Contamination is known to have occurred during the field collection process. Validity of reported value may be compromised	The source of contamination, if known, should be provided in the Exception to Method Text	Lab, QC
<b>KCP</b>	Known Contamination, lab preparation	Contamination	Contamination is known to have occurred during the laboratory preparation process. Validity of reported value may be compromised	The source of contamination, if known, should be provided in the Exception to Method Text	Lab, QC
<b>KCX</b>	Known Contamination, unknown	Contamination	Contamination is known to have occurred but the source of that contamination is unknown. Validity of reported value may be compromised		Lab, QC
<b>LAC</b>	No Result Reported, lab accident	No Result Reported	Analysis was halted because a laboratory accident either destroyed the sample or rendered it not suitable for analysis. No result value was reported	Information about the lab accident should be provided in the Exception to Method Text	Lab, QC
<b>LOB</b>	Likely Biased Low	Other	Reported value is probably biased low as evidenced by LMS (matrix spike, lab) results, SRM (reference material, standard) recovery or other internal lab QC data. Reported value is not considered invalid, however		QC



## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<u>Code</u>	<u>Name</u>	<u>Group</u>	<u>Description</u>	<u>Reporting Instruction Description</u>	<u>Assignor</u>
<b>LTL</b>	Operating Range, less than	Limit	Reported value is below the valid operating range of the analytical system, quantitative process, or qualitative process, or reported value is less than the lowest calibration standard. Validity of reported value may be		Lab, QC
<b>MBK</b>	Blank, detected below MDL	Other	Analyte was detected in a related lab blank at a concentration below the method detection limit (MDL) and/or blank action limit, however the related lab blank did not fail		Lab, QC
<b>MDL</b>	Method Detection Limit, less than	Limit	Analyte produced an instrument response but reported value is below the calculated method detection limit. Validity of reported value may be compromised	Information about detection limits should be provided in the Project QA/QC Summary	Lab, QC
<b>NAI</b>	No Result Reported, interference	No Result Reported	A valid result could not be obtained from the analysis due to interference. Analysis was halted. No result value was reported	Information about the type of interference should be provided in the Exception to Method Text	Lab, QC
<b>NRR</b>	No Result Reported, other	No Result Reported	Result value was not determined or entered for reasons other than those presented in this list. No result value was reported	The reason the result was not determined or entered should be provided in the Exception to Method Text	Lab, QC
<b>NSQ</b>	No Result Reported, insufficient quantity of sample	No Result Reported	Result value could not be obtained due to insufficient quantity of the sample. No result value was reported		Lab, QC
<b>NWL</b>	Operating Range, not within	Limit	Reported value is outside (above or below not specified) the valid operating range of the analytical system, quantitative process, or qualitative process, or outside the calibration standard. Validity of reported		Lab, QC
<b>OTHER</b>	Other	Other	Validity of reported value may be compromised for reasons other than those presented in this list	The reason the validity of the reported value may be compromised should be provided in the Result Description	Lab, QC
<b>PNQ</b>	No Quantifiable Result Reported	No Result Reported	Analyte was present in the sample but was not quantifiable. No result value was reported		Lab, QC
<b>PPD</b>	Spiked Blank Duplicate, failed	QC Failed	Analysis results showed unacceptable duplicate precision between laboratory prepared spiked blank duplicates. Validity of reported value may be compromised		Lab, QC
<b>REJ</b>	Value Rejected	Other	Reported value was rejected by the laboratory. Value was not utilized in the calculation of any results	The reason that the value was rejected should be provided in the Exception to Method Text	Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b>Code</b>	<b>Name</b>	<b>Group</b>	<b>Description</b>	<b>Reporting Instruction Description</b>	<b>Assignor</b>
<b>REQ</b>	Method Not Approved, re-analyze	Procedure	Analytic method for the reported value was not approved. The sample was re-analyzed using a different method		Lab, QC
<b>RET</b>	Value Not Approved	Other	Reported value is not approved by laboratory management. The sample was re-analyzed with no change in the method. Validity of reported value may be compromised	The reason that the value is not approved should be provided in the Exception to Method Text	Lab, QC
<b>REX</b>	Re-Prepared	Procedure	Reported value was generated from a re-preparation of the same sample		Lab, QC
<b>RIN</b>	Re-Analyzed	Procedure	Reported value was generated from a re-analysis of the same sample extract or aliquot using the same method		Lab, QC
<b>RSL</b>	Resloped	Procedure	Reported value was quantified from a resloped calibration curve during the instrument run		Lab, QC
<b>SCA</b>	Suspected Contamination, lab analysis	Contamination	Contamination is suspected to have occurred during the laboratory analysis process. Validity of reported value may be compromised	The source of contamination, if known, should be provided in the Exception to Method Text	Lab, QC
<b>SCF</b>	Suspected Contamination, field	Contamination	Contamination is suspected to have occurred during the field collection process. Validity of reported value may be compromised	The source of contamination, if known, should be provided in the Exception to Method Text	Lab, QC
<b>SCP</b>	Suspected Contamination, lab preparation	Contamination	Contamination is suspected to have occurred during the laboratory preparation process. Validity of reported value may be compromised	The source of contamination, if known, should be provided in the Exception to Method Text	Lab, QC
<b>SCX</b>	Suspected Contamination, unknown	Contamination	Contamination is suspected to have occurred but the source of that contamination is unknown. Validity of reported value may be compromised		Lab, QC
<b>SDL</b>	System Detection Limit, less than	Limit	Analyte produced an instrument response but reported value is below the calculated system detection limit. Validity of reported value may be compromised	Information about detection limits should be provided in the Project QA/QC Summary	Lab, QC
<b>SFF</b>	Field Spike Blank, failed	QC Failed	A field spike blank associated with this analysis failed the acceptance criteria. Validity of reported value may be compromised		Lab, QC

## GLENDA LAB REMARK CODES

(Lab\_rmrk.xls)

<b><u>Code</u></b>	<b><u>Name</u></b>	<b><u>Group</u></b>	<b><u>Description</u></b>	<b><u>Reporting Instruction Description</u></b>	<b><u>Assignor</u></b>
<b>TIE</b>	Estimated value, no calibration standard	Estimated Value	Reported value has been estimated because no calibration standard was analyzed		Lab, QC
<b>UDL</b>	Sample-specific Detection Limit, less than	Limit	Analyte produced an instrument response but reported value is below the calculated sample-specific detection limit. Validity of reported value may be compromised	Information about detection limits should be provided in the Project QA/QC Summary	Lab, QC
<b>UNC</b>	Value Not Confirmed	Other	Reported value could not be confirmed by using an auxiliary analytic method (e.g., an alternate GC column). Validity of reported value may be compromised	Information about the confirmation technique should be provided in the Analytical Method or the Exception to Method Text	Lab, QC
<b>UND</b>	Analyte Not Detected	Limit	Analyte produced no instrument response above noise		Lab, QC