

Chlorophyll a Preparation

Survey ID	Visit ID	Station ID	Preparation Batch ID

Sample IDs	Depth Code	Check Mark	Remarks

Sample volume (mLs)	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials) XXX
		:	

Survey ID	Visit ID	Station ID	Preparation Batch ID

Sample IDs	Depth Code	Check Mark	Remarks

Sample volume (mLs)	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials)XXX
		:	

Notes:

1. Refer to LG200 for depth code abbreviations and definitions.
2. Refer to Attachment A of the WQS QAPP, LG400, or LG401 for more information on integrated samples.

PHYTOPLANKTON PRESERVATION

GLNPO's WQS

Survey ID	Visit ID	Station ID	Preparation Batch ID

Sample IDs	Depth Code	Check Mark	Remarks

Sample volume (mLs)	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials) XXX
		:	

Survey ID	Visit ID	Station ID	Preparation Batch ID

Sample IDs	Depth code	Check mark	Remarks

Sample volume (mLs)	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials) XXX
		:	

Survey ID	Visit ID	Station ID	Preparation Batch ID

Sample IDs	Depth code	Check mark	Remarks

Sample volume (mLs)	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials) XXX
		:	

Notes:

1. Refer to LG200 for depth code abbreviations and definitions.
2. Refer to Attachment A of the WQS QAPP, LG400, or LG401 for more information on integrated samples.

Nutrients Preparation

Survey ID	Visit ID	Station ID	Preparation Batch ID	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials) XXX

Sample IDs	Depth Code	Check Mark	Remarks

Survey ID	Visit ID	Station ID	Preparation Batch ID	Preparation Date (mm/dd/yyyy)	Preparation Finish Time (Shiptime, military)	Personnel (initials) XXX

Sample IDs	Depth Code	Check Mark	Remarks

NOTE: Refer to LG200 for depth code abbreviations and definitions.

POC, PN, PP Preparation

Survey ID	Visit ID	Station ID	Batch ID	Date (mm/dd/yyyy)	Time (Shiptime,military)	Personnel (Initials)

Sample ID	Depth Code	Volume (mL)			Remarks
		POC	PN	PP	

Survey ID	Visit ID	Station ID	BatchID	Date (mm/dd/yyyy)	Time (Shiptime,military)	Personnel (Initials)

Sample ID	Depth Code	Volume (mL)			Remarks
		POC	PN	PP	

Survey ID	Visit ID	Station ID	BatchID	Date (mm/dd/yyyy)	Time (Shiptime,military)	Personnel (Initials)

Sample ID	Depth Code	Volume (mL)			Remarks
		POC	PN	PP	

NOTE: Refer to LG200 for depth code abbreviations and definitions.

TSS Preparation

Survey ID	Visit ID	Station ID	Filtration Batch ID	Filtration Date (mm/dd/yyyy)	Filtration Time (Shiptime, military)	Personnel (initials)XXX
Sample ID	Preparation Batch ID	Filter Number	Volume Sample Filtered (L)	Remarks		

Survey ID	Visit ID	Station ID	Filtration Batch ID	Filtration Date (mm/dd/yyyy)	Filtration Time (Shiptime, military)	Personnel (initials) XXX
Sample ID	Preparation Batch ID	Filter Number	Volume Sample Filtered (L)	Remarks		

Survey ID	Visit ID	Station ID	Filtration Batch ID	Filtration Date (mm/dd/yyyy)	Filtration Time (Shiptime, military)	Personnel (initials) XXX
Sample ID	Preparation Batch ID	Filter Number	Volume Sample Filtered (L)	Remarks		

Preparation of Quality Assurance Samples

GLNPO WQS

Survey ID	Visit ID	Station ID

Method SOP	Sample ID	QCID Code	Prep. Date (mm/dd/yyyy)	Prep. Time (Shiptime, military)	Analyst (initials) XXX	Analyte Code	Target Value	Target Units	Remarks/Source Material

1. Each control standard sampleID represents material in a bottle. When the material in a bottle is replenished, a new sampleID results.
2. pH control standard sampleIDs remain constant for one lake, unless small bottle refilled from one liter bottle before lake is finished.
3. Turbidity control standard sampleIDs remain constant for the duration of the commercial bottle.
4. Alkalinity control standard sampleIDs change when the one liter bottle is refilled.
5. Conductivity control standard sampleIDs change when the one liter bottle is refilled.

Calibration Data of Board Chemistry Instruments

Survey ID

LAKE (Circle Selection)

SUPERIOR	MICHIGAN	HURON	ERIE	ONTARIO
(SU)	(MI)	(HU)	(ER)	(ON)

Calibration of On Board analytical instruments should be performed at least once at the beginning of each Lake Survey

pH Meter	Buffer 4	Buffer 7	Buffer 10
	(SU)	(SU)	(SU)
pH	N/A	*	*
pH - Alkalinity	*	*	N/A

Turbidity Meter	Before Adjusting	After Adjusting
0 NTU		
20 NTU		

*Record Temperature at which standardization was performed

Date of Calibration (mm/dd/yyyy)	Time of Calibration (Shiptime, military)	Analyst (Initials, XXX)

Conductivity Stds.	Readings	Turbidity Stds.	NTU VALUE
106.1 umho/cm		Calibration 0	
210.3 umho/cm		Calibration 0.4	
313.5 umho/cm		Calibration 2.0	
415.8 umho/cm		Calibration 8.0	
		Calibration 20.0	

Notes:

1. Formazin Turbidity Standards should be prepared fresh daily.
2. This form is used for the sole purpose of documenting instrument calibrations only.
3. Calibration values of pH, Alkalinity & Turbidity meters should be updated w/ Stds. pH 7(pH), pH 4 (Alkalinity) & 20 NTU(Turbidity) at the beginning of each shift.

Calibration Data of Board Chemistry Instruments
Shiftwise Standardization

StationID	Date/Time (Shiptime)	Analyst	pH determination buffer 7	Temp. of Standardization	Alk determination buffer 4	Temp. of Standardization	Turbidity 20 NTU	Turbidity Empty Compartment
	(mm/dd/yyyy hh:mm)	(initials, XXX)	(reading before standardization)	(°C)	(reading before standardization)	(°C)	(before adjusting to 20)	before/after

Control Standards Data of Board Chemistry Parameters

Survey ID	Visit ID	Station ID

LAKE (Circle Selection)				
SUPERIOR (SU)	MICHIGAN (MI)	HURON (HU)	ERIE (ER)	ONTARIO (ON)

Warning Limits for Board Chemistry

SAMPLE ID	Parameter	Control Standard	Measured Value	Remarks	Control Standard	Warning Limits	*Control Limits
	pH - (Low)	6.86 (SU)			Low - pH 6.86	6.66 - 7.6	6.56 - 7.16
	pH - (High)	9.18 (SU)			High - pH 9.18	8.98 - 9.38	8.88 - 9.48
	Conductivity (Low)	196.5(umhos/cm)			Low Conductivity 196.5	194.5 - 198.5	193.5 - 199.5
	Conductivity (High)	293.3 (umhos/cm)			High Conductivity 293.3	291.3 - 295.3	290.3 - 296.3
	Alkalinity (Low)	40 (mg/L)			Low Alkalinity 40	38.6 - 41.4	38 - 42
	Alkalinity (High)	100 (mg/L)			High Alkalinity 100	98 - 102	97 - 103
	Turbidity (Low)	0.5 (NTU)			Low Turbidity 0.5	0.3 - 0.7	0.2 - 0.8
	Turbidity (High)	10 (NTU)			High Turbidity 10	8.6 - 11.4	8.0 - 12

Date of Control Check	Time of Control Check	Analyst
(mm/dd/yyyy)	(Shiptime, military)	(initials)

Note: Control Standards should be analyzed at the onset, starting with the initial calibration of instruments for each lake survey and before the end of each 12-hour shift.

*Applicable instruments should be re-calibrated and samples re-analyzed, if any control standards measured are not within range of the Control Limits.

Board Chemistry Data

Survey ID	Visit ID	Station ID	Analytical Batch ID	Analytical Date (mm/dd/yyyy)	Analytical Time (Shiptime)	Analyst (Initials) XXX

Sample ID	Depth Code	pH (SU)	Specific Conductance (umhos/cm)	*Total Alkalinity (mg/L)	Turbidity (NTU)	Remarks

**Total Alkalinity Calculation:*

Volume of Titrant used (ml) X 10

NOTE: Refer to LG200 for depth code abbreviations and definitions.

Dissolved Oxygen Data (Winkler)

Survey ID	Visit ID	Station ID	Analytical Batch ID	Analytical Date (mm/dd/yyyy)	Analytical Time (Shiptime, military)	Analyst (initials, XXX)

Sample ID	Titrant Used D.O. (mL)	BOD Bottle Volume (mL)	Volume Corrected D.O. (mg/L)	Temperature (Celsius)	Barometric Pressure (mb)	Corrected Table Value (mg/L)	Remarks

Calculation of Volume Corrected D.O.

Titant Used (mL) x 60.8 (mL) / BOD Bottle Volume (mL)

Corrected Table Value

Value from Temperature table x barometric pressure/std pressure

At least one saturated sample is analyzed on each shift

Method Performance Criteria		
QC Type	Minimum Frequency	Acceptance Criteria
Lab Duplicate	Each Master Station	Absolute Difference < 0.2 mg/L
	DO Surveys: All SRF and B-1 samples	
Lab Accuracy Check, Saturated Sample	At the beginning of each lake of a regular survey	+/- 0.5 mg/L, compared to theoretical
	DO Surveys: At the beginning and once per shift	