

Assessment of Use of Air Sampling Collection Methods Following an Outdoor *Bacillus Anthracis* Contamination

2018 EPA International Decontamination
Research and Development Conference

May 9, 2018



RTI International

Jonathan Thornburg, Paul Mobley, Jean Kim, Prakash Doraiswamy,
and Christina Murata

US EPA

Sang Don Lee, Worth Calfee, John Archer, Leroy Mickelsen, and
Timothy Boe

Introduction

- EPA has the responsibility for protecting human health and the environment in the event of a release of biological material in an urban area.
- EPA's toolbox includes approaches for surface, soil, water, and air sample collection.
- This research is assessing air sampling methods for *Bacillus anthracis* following a wide area contamination.
 - Objective 1: Review the literature to identify the best available air sampling methods for outdoor spore sampling.
 - Objective 2: Evaluate different air sampling strategies and identify operational gaps.


Presentation Objectives

- Discuss the factors that affect the bioaerosol concentration produced by resuspension and subsequent impact on network design.
- Preliminary results examining a few simple network designs.

Approach for Evaluating Air Sampling Strategies

- Developed a system performance model in MATLAB to evaluate different air sampling strategies.
- Model components
 - Spore air concentration
 - Scenario definition
 - Spore emission rate caused by resuspension
 - Spore dispersion
 - Daily average spore concentration in the x,y plane at multiple heights
 - Air sampling strategies
 - Air sampler technical specifications: low flow and high flow systems
 - Air sample costs: equipment costs and per sample costs
 - Network evaluation
 - Number and location of samplers that collect 1 spore
 - Unitized cost per sample per strategy

System Performance Model Framework




Data Sources and Assumptions

- Data Sources
 - Used publicly available peer-reviewed data when available.
 - Non-peer reviewed but publicly available data used when necessary.
- Key Assumptions
 - Surface loading along the line of release.
 - Decay function to relate resuspension fraction to surface loading
 - Easily resuspended particles are aerosolized first.
 - Decreasing resuspension fraction over time.
 - Did not include rain or mitigation influences on surface loading.

Scenario Modeled for This Presentation

- National Planning Scenario #2 release.
- Urban metropolis with uniform road grid covering 36 km².
- 12 time periods from Oct. 2001 to Aug. 2002.
 - 6 fall, 4 spring, 1 winter, and 1 summer.
 - A period is 28 days, with decon @ day 15.
- Input variables constant or allowed to fluctuate.
 - Activity patterns tied to day of the week.
 - Initial resuspension fraction.
 - Surface loading.
- Assume normal activities after release.
- 121 sample points.
- Sampler heights of 2, 4, 10, 20, 30, 40 and 50 m.




General Results & Observations

- Decontamination at Day 15 effectively reduced bioaerosol concentration to zero, even adjacent to the point of release
- Selectively choosing results can be misleading and generate wrong conclusions.
- Easy to identify statistically significant or insignificant differences in the bioaerosol concentration.
 - Emission rate caused by resuspension decreases each day because of source depletion.
 - Meteorology influences on wind speed & direction, boundary layer thickness.
 - Distance of the sampler from the initial release location.
 - Height of the sampler above the ground.
- **Need to consider all 3.4 million bioaerosol concentrations produced during this modeled scenario when evaluating the performance of a sampler network.**

Influences on Daily Average Bioaerosol Concentration

- Statistical model was a general linear model with sampler location as a categorical variable and all other variables as continuous.
- Results
 - Days since release: p-value < 0.0001
 - Meteorology: p-value = 0.328
 - Sampler height: p-value < 0.0001
 - Sampler location (x,y plane): p-value < 0.0001


Daily Average Bioaerosol Concentration



- All inputs constant except for meteorology.
- 12 scenarios modeled.
- Average concentration across the 36 km² area.

- Bioaerosol concentration decreases over time because of source depletion.
- Concentration fluctuation between scenarios illustrates the variability caused by meteorology, although a statistically insignificant variable.





Sampler Height Influence: All other inputs constant




- 2, 4, 10 m concentrations always statistically similar.
- On certain days, the concentration at 20 m is the same as the lower heights.
- Concentrations at 30, 40, and 50 m decrease with height as expected.

Number of Samplers that Collect 1 Spore in 24 Hours

- Gives an initial understanding of required sampler density
- High (300 Lpm) and low flow (10 Lpm) samplers
- All samples at 4 m (assumed easy to deploy samplers and collect samples)
- Average of all 12 time periods, all other variables constant
- 4 sampler deployment patterns (121, 77, 45, 19 samplers)




High Flow Sampler Network



- Day 1: 100% of samplers collect at least 1 spore.
- Day 14: “positive” samples concentrated around point of release.
- Error bars indicate the influence of meteorology.

- Dense network = more “positive” samples and a faster rate of decrease in the number of “positive” samples over time.
- The difference between HF:121 and other HF networks equals the number of “positive” samples missed by using a lower density network.

Low Flow Sampler Network



- Day 1: Less than 100% of samplers collect at least 1 spore.
- Day 14: “positive” samples concentrated around point of release.

- Network density trends hold: dense network = more “positive” samples and a faster rate of decrease.
- The relative number of “missed” samples decreases for a low-flow sampler network.

Summary

- We developed a MATLAB tool to evaluate bioaerosol sampler network strategies for deployment in an urban metropolis.
- Bioaerosol concentration resulting from resuspension is a function of:
 - Number of days since release
 - Sampler location and height
- Meteorology causes fluctuations in the bioaerosol concentration but was a statistically insignificant variable at the network level.


Summary (cont.)

- The detection of resuspended spores by the network increased when high flow samplers used and at higher sampler density.
- Limiting bioaerosol sample collection to the area near the release point missed detectable spores that transport several kilometers downwind.
- Next Steps
 - Include native samplers: building outdoor air intake filters.
 - Mixed strategy: combination of high flow, low flow, and native samples.
 - Work costs into simulations to optimize detection probability versus cost.

Disclaimer


This research is funded under EPA Contract EP-C-16-016. The presentation was reviewed by EPA. The views expressed in this document are solely those of the authors and do not necessarily reflect those of the Agency. EPA does not endorse any products or commercial services mentioned in this publication.

Sampler Height Influence: All other inputs constant




Sampler Height Influence: All other inputs constant

Scenario 960 (Day 14)



Spatial Concentration & Sampler Location

Scenario 4656, Day 10, 2m



- Highest concentrations at the release point because of meteorology
- Light, southwest wind
- “Icicles” are modeled concentrations
- Dimples and ridges caused by the spline fitting algorithm in the graphics program

Definitions and Conversions

- $1 \text{ CFU/m}^3 = 1\text{E-}3 \text{ ACPLA}$
 - Or $100 \text{ ACPLA} = 1\text{E+}5 \text{ CFU/m}^3$, lowest possible detection limit for real-time instrumentation
- Low Flow Sampler = 10 Lpm (SKC Leland Pump)
 - $\sim 0.07 \text{ CFU/m}^3$ to collect 1 spore in 24 hours
- High Flow Sampler = 300 Lpm (XMX, etc.)
 - $\sim 0.003 \text{ CFU/m}^3$ to collect 1 spore in 24 hours

High and Low Flow Networks: What is Missed?

Day	Sampler Density	High Flow: 300 Lpm	Low Flow: 10 Lpm
1	77	44 ± 0	37 ± 9
	45	76 ± 0	66 ± 12
	19	102 ± 0	89 ± 17
7	77	26 ± 8	9 ± 2
	45	51 ± 12	17 ± 4
	19	67 ± 17	23 ± 5
14	77	14 ± 5	2 ± 2
	45	27 ± 8	5 ± 3
	19	35 ± 10	6 ± 4