





# PCB Remediation Waste Cleanup and Disposal



PCB Guidance Materials, Links and  
EPA Region 4 PCB Contact  
Information

U.S. EPA, Region 4  
2021




# PCBs Overview

- PCBs – Properties and health concerns
- Regulatory history and structure
- Cleanup options
- Disposal options
- Resources
- Case Study
- Regional PCB contacts
- Questions







Flame retardant



Low electrical conductivity



Low vapor pressure



Colorless




Viscous liquid or solid




Odorless




# Physical Properties of PCBs




Used as mixtures of congeners commonly called Aroclors  
(Aroclor 1254 → 54% chlorine by mass)



Lipophilic




Stable to aging




209 Congeners

# Chemical Properties of PCBs


# Uses of PCBs (~1950-1978)




Gaskets & Damping felt




Heat transfer fluid




Fluorescent light ballasts




Construction materials  
(ex. caulk, sealants, tiles,  
etc.)




Cutting oils



Plasticizer




Vacuum pump fluid



Hydraulic fluid




Lubricants



Dielectric fluid


# Uses of PCBs (continued)



**Inks and paints**




**Pesticide extenders**



**Carbonless copy  
paper**




**Fuel tank coatings**



**Dusting Agent**



**Microscopy**  
(mounting media & immersion oil)



**Electric cable  
insulation**




**Casting Wax**



**Adhesives**

# Use of PCBs Between 1930-1975



1930-1975  
A Total of  
1.4 Billion lbs was produced



# Environmental Transport

PCBs are persistent, bioaccumulative, and can be transported long distances

PCBs have been found in animals, snow, and sea water in areas far away from where they were released into the environment.





# PCBs – Regulatory History




- **Manufactured in U.S. from 1929 – 1979**
- **Toxic Substances Control Act passed by Congress in 1976**
  - TSCA Section 6(e) banned the manufacture and use of PCBs
  - Allowed EPA to authorize limited uses through a rulemaking process
  - EPA issued regulations in 1979 for the use, manufacturing, processing, distribution in commerce, cleanup, and disposal of PCBs
  - 1998 “Mega Rule” – major changes to the cleanup and disposal sections
- **TSCA PCB Regulations found at 40 CFR 761**
- **PCB Cleanup and Disposal Program evolved separately from other cleanup and disposal programs**
  - Transferred the program to the “RCRA Office” (Office of Resource Conservation and Recovery) in 2007 but the regulations stayed the same
  - Regulations regarding the use of PCBs are still managed by the Office of Pollution Prevention and Toxics





# Implementation of PCB Regs

Unlike RCRA, TSCA authority is not delegated to States.




# Indicators that you might have PCBs on your hands:




- ❖ Equipment - Labels, trade names, manufactured pre-1979
- ❖ Building materials – Product labels, structure built or renovated pre-1979
- ❖ Cleanup Areas – Wherever the following items were manufactured, stored, used, serviced, or transported
  - ❖ Electrical equipment, hydraulic presses, vacuum systems, natural gas compressor systems, aircraft hydraulic oils, dust suppression, etc.

*However, even without these indicators, PCBs may still be present because:*

- ❖ Labels were not required prior to 1979
- ❖ Servicing of uncontaminated equipment has led to cross-contamination and unintentional dilution
- ❖ Some uses were not well recorded





PCB Painted surface



# PCB Bulk Product Waste

(see 40 CFR 761.3 for full detail)

Any building built or renovated before 1979 is likely to have PCB-containing Bulk Product Waste (e.g., fluorescent light ballasts, caulk, paint, ceiling tiles, spray-on fireproofing, floor finishes).

1998 “Mega Rule” – major changes to the cleanup and disposal sections


Manufactured products with  $\geq 50$  ppm are unauthorized and must be removed/disposed of under § 761.62.

**Just be aware that there may be other PCB-containing waste at your site.**



# 1998 "Mega Rule" – major changes to the cleanup and disposal sections


**PCB Bulk Product Waste**  
 see 40 CFR 761.3  
 for full details






# Definition of "PCB Remediation Waste"

see 40 CFR 761.3 for full details



# Definition of “PCB Remediation Waste”

see 40 CFR 761.3 for full detail



**Key Takeaway Point:**  
Even if the material is < 50 ppm, it may still be regulated




# PCB Remediation Waste Cleanup and Disposal Option Basics

**NOT PCB Remediation Waste**

No cleanup or disposal obligations  
No interaction with EPA  
Any landfill

\*PCB Remediation Waste resulting from a spill or release before 1978 is not subject to the cleanup requirements of the regulations (unless the RA makes a finding of unacceptable risk) but is subject to the disposal requirements if it is picked up (see 40 CFR 761.50(b)(3)).

**PCB Remediation Waste\***





# Some Things to Remember



- ❖ ***How you sample matters- “As found” refers to in-situ concentrations or to stockpiles if the waste was already in place at the time of site investigation or characterization.***
- ❖ ***For example, you may not dilute the as-found concentration of the contaminated soil during excavation or other management activities. Soils must not be disturbed outside of sampling or diluted (e.g., excavated, placed on a pile, and sampled afterwards) before conducting in-situ characterization sampling.***
- ❖ ***How you analyze the samples matters- 40 CFR Part 761, Subpart N and O, PCB Extraction and Analytical Methods***
- ❖ ***The PCB regulations require the use of the Ultrasonic (EPA SW 846 Method 3550C) or Soxhlet (EPA SW-846 Method 3540C) extraction methods (preparation method). (EPA recommends the use of the Soxhlet extraction procedure because of the poor sample extraction efficiency of the ultrasonic method and States may not approve of M3550C.)***

***Use Method 8082 for analysis.***

# Spill Cleanup Policy



- ❖ Subpart G of PCB regulations; however, it is a “policy”
- ❖ Intended for spills <72 hours old
- ❖ No need to notify EPA; however, need to keep a report

# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(1)



## Applicability-

- ❖ May **not** be used to clean up:
  - ❖ Surface or Groundwater
  - ❖ Sediments in surface water or groundwater ecosystems
  - ❖ Sewers or sewage treatment systems
  - ❖ Any private or public drinking water sources or distribution systems
  - ❖ Grazing lands
  - ❖ Vegetable gardens

# PCB Remediation Waste

## SELF-IMPLEMENTING CLEANUP AND DISPOSAL

§ 761.61(a)(2)



### Site Characterization- References Subpart N and Subpart O

- ❖ Requires *Sampling Bulk PCB Remediation Waste and Porous Surfaces*- a grid interval of 3 meters and the procedures in Sections 761.283 (number of samples) and 761.286 (sample size and procedure) for PCB remediation wastes.
- ❖ Subpart O requirements for disposal as <50 ppm.
- ❖ Compositing cannot be used for characterization but can be used for verification.

# PCB Remediation Waste

## SELF-IMPLEMENTING CLEANUP AND DISPOSAL

§ 761.61(a)(2)



### Site Characterization- References Subpart N and Subpart O

*There are very specific site characterization sampling. If the characterization deviates in any way from the regulations, the self-implementing cleanup and disposal option is not applicable...*

*However, a “hybrid Approval” may be issued by EPA to allow an alternate sampling characterization.*

# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(2)




## Site Characterization- Continued

- ❖ 761.272-Chemical extraction and analysis of samples

*There are very specific methods for extraction and chemical analysis. If the methods used deviate in any way from the regulatory requirements, sampling may have to be repeated. EPA may require further sampling with the appropriate methods.*

*(EPA prefers extraction method 3540.)*

*Deviation from the extraction methods must be done through Subpart Q.*



# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(3)



## Notification and Certification

Regulation requires notification 30 days prior to the date that the cleanup of a site begins.

### *However:*

- ❖ *The property owner is responsible for making sure that EPA receives the notification.*
- ❖ *If there are comments within the 30 days or issues with the plan, you can not proceed after the 30-days has passed.*
- ❖ *The plan may proceed after 30 days without EPA approval...however, if any aspect of the 761.61(a) requirements are not followed, the 30 day default provision does not apply.*

**THE FAILURE OF EPA TO RESPOND IN 30 DAYS IS NOT IMPLIED/IMPLICIT APPROVAL.**

# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(3)



## Notification and Certification

*(Required elements for .61(a))*

- ❖ Pre-Cleanup Site Characterization
- ❖ PCB Cleanup Plan
- ❖ Written Certification



EPA can provide a checklist to assist in the development of the Notification.

EPA has developed a PCB Facility Approval Streamlining Toolbox (PCB FAST).

<https://www.epa.gov/pcbs/pcb-facility-approval-streamlining-toolbox-fast-streamlining-cleanup-approval-process>



# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(3)



## Notification and Certification

*(Required elements for Both 61(a) and 61(c))*

### Pre-Cleanup Site Characterization (completed or proposed)-

- ❖ The horizontal and vertical extent of the contamination must be delineated to **less than 1 mg/kg PCBs**. For 761.61(c), the standard could be lower.
- ❖ EPA does not distinguish between saturated and unsaturated soils.
- ❖ Groundwater samples should be collected from wells close to where PCBs exceed the soil cleanup target level. Groundwater should be analyzed using Method 8260 to determine volatile organic compounds; including but not limited to, Chlorobenzenes, Tetrachloroethylene (PCE), and Trichloroethylene (TCE).
- ❖ In the event there is a line of evidence that indicates a solvent carrier of PCB was part of the discharge, delineation of PCBs in soil below the water table may be required to determine if a source below the water table is present on top of the confining layer.

# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(3)



## **Notification and Certification**

*(Required elements for Both 61(a) and 61(c))*

### **Pre-Cleanup Site Characterization (completed or proposed)-**

- ❖ Summary of the procedures used to sample contaminated and adjacent areas.
- ❖ A table and/or cleanup site map showing PCB concentrations measured in all pre-cleanup characterization samples.
- ❖ Copies of the laboratory analytical reports of the characterization sampling, including field and laboratory quality assurance/quality control samples should be provided with the notification to EPA 761.61(a)(3)(i)(C).
- ❖ The location and extent of the identified contaminated area-pictures and maps with sample collection sites cross referenced to the sample identification numbers in the data summary from paragraph (a)(3)(i)(B) of this section. (40 CFR 761.61(a)(3)(i)(C))



# PCB Remediation Waste Self-Implementing Cleanup and Disposal


§761.61(a)(3)

## Notification and Certification

*(Required elements for Both 61(a) and 61(c))*

- ❖ PCB Cleanup Plan- includes a schedule, disposal technology, and approach. This plan should contain options and contingencies to be used if unanticipated higher concentrations or wider distributions of PCB remediation waste are found or other obstacles force changes in the cleanup approach.

Gantt Chart



*If this...  
Then that...*

# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(3)



## **CLEANUP REQUIREMENTS**

For BULK PCB REMEDIATION WASTE and POROUS SURFACES

High Occupancy	Low Occupancy
<p><b><u>Definition*</u></b>  <math>\geq 6.7</math> hrs/wk without dermal or respiratory protection</p> <p><b><u>Cleanup Standards</u></b>  <math>\leq 1</math>ppm in residual waste or porous surface w/o further conditions</p> <p><math>&gt; 1</math> to <math>\leq 10</math> ppm if site covered w/ compliant cap and institutional control implemented (deed restriction)</p>	<p><b><u>Definition*</u></b>  <math>&lt; 6.7</math> hrs/wk without dermal or respiratory protection</p> <p><b><u>Cleanup Standards</u></b>  <math>\leq 25</math> ppm in residual waste or porous surface, unless otherwise specified in 40 CFR 761.61(a)(4)(i)(B) &amp; institutional control implemented (deed restriction)</p> <p><math>&gt; 25</math> ppm to <math>\leq 50</math> ppm if secured by fence, marked per 40 CFR 761.45 &amp; institutional control implemented (deed restriction)</p> <p><math>&gt; 25</math> ppm to <math>\leq 100</math> ppm w/ appropriate cap &amp; institutional control implemented (deed restriction)</p>

\* See 40 CFR 761.3 for the complete definition

# PCB Remediation Waste Self-Implementing Cleanup and Disposal

§761.61(a)(3)



- ❖ **Written Certification-** as defined in §761.3 **and** certifying that all sampling plans, sample collection procedures, sample preparation procedures, extraction procedures, and instrumental/chemical analysis procedures used to assess or characterize the PCB contamination at the cleanup site are on file at the location designated in the certificate and are available for EPA inspection.

The Certification required in 40 CFR 761.61(a)(3)(i)(E) **must** be signed by the site owner. The Certification is part of the Notification.



# PCB Disposal Options

The general, most conservative disposal options are a TSCA-approved landfill (for non-liquids) or a TSCA-approved incinerator (for liquids).


Other disposal options are available depending on the media, concentration, and the cleanup option.

Depending on remedial option selected, the disposal options may be limited.

# PCB- Things to Remember...



- PCBs are regulated by the U.S. EPA under the Toxic Substances Control Act
- A few key points:
  - When identified, appropriate management and disposal of materials containing PCBs is required under TSCA regulations.
  - Regulations prohibit the use of PCBs at greater than 50 ppm in caulk and other non-liquid products, including continued use of products already in place.
  - If PCBs greater than 1 ppm remain onsite there are other requirements (**e.g., deed restrictions, monitoring and maintenance plans, financial assurance**).
  - PCB regulations may govern owners, operators, and/or persons conducting cleanup of PCB-contaminated property where the PCB contamination exceeds allowable concentrations under the regulations.
  - TSCA authority is not delegated to the states; therefore, both TSCA and state regulations will apply.



Is TSCA applicable at Brownfield sites?

**Yes**, for those sites where cleanup of PCB remediation waste is required.

Is TSCA applicable at RCRA Corrective Action sites?

**Yes**, for those sites where cleanup of PCB remediation waste is required.

Is TSCA applicable at Superfund sites?

**Yes**, for those sites where cleanup of PCB remediation waste is required.

## Other Questions Answered...





❖ Contact your EPA Regional PCB Coordinator early – as soon as you think you might have or know you have PCBs on your cleanup site.

## Key Advice

❖ Why?

The PCB regulations require a distinct process that often requires EPA notification/approval, **and delays** are likely if EPA is not involved early. EPA's interest is to make sure that the requirements of the federal PCB regulations are met while trying to avoid duplication of documentation and effort.



## **SELF-IMPLEMENTING CLEANUP AND DISPOSAL**


*(§ 761.61(a)) is not always the best option or an available option. It has very prescriptive sampling cleanup and disposal requirements. It is meant for small sites (<1 acre).*

***Make sure to use the appropriate PCB sample extraction and chemical analysis methods.***

***Contact the Regional PCB Coordinator early in the project if PCBs are found.***

# **Three Take-Away Points to Remember**

# Resources





➤ Region 4 PCB Website

<https://www.epa.gov/pcbs/epa-region-4-polychlorinated-biphenyls-pcbs>

➤ Region 4 Interactive Map of Cleanup Sites

<https://epa.maps.arcgis.com/apps/webappviewer/index.html?id=6ef48abc71e744b4b07a5635f77dfea9>





# Resources

NOTE- All communication and submittals to the EPA should be electronic.

A more complete list of PCB guidance can be found at the EPA website.

<https://www.epa.gov/pcbs>

## ❖ **Comprehensive Q & A Manual**

Commonly asked questions on all manner of topics

<https://www.epa.gov/pcbs/polychlorinated-biphenyl-pcb-question-and-answer-manual-and-response-comment-documents>

## ❖ **Sampling Guidance**

How to sample natural gas pipeline, apply a grid sampling plan, do wipe sampling, etc.

<https://www.epa.gov/pcbs/guidance-sampling-certain-types-wastes-containing-polychlorinated-biphenyls-pcbs>

## ❖ **Checklists for 61(a) and 61(c) cleanup applications**

Excellent resource for those submitting cleanup plan

<https://www.epa.gov/pcbs/managing-remediation-waste-polychlorinated-biphenyls-pcbs-cleanups>



# Resources

RCRA Info/PCB Module- All information is stored in this database.

## ❖ PCBs in Fluorescent Light Ballasts

<https://www.epa.gov/sites/production/files/2020-07/documents/pcb-flb-factsheet-final-july-2020.pdf>

## ❖ PCBs in Dental Office X-ray Machines

<https://www.epa.gov/sites/production/files/2020-07/documents/pcb-x-ray-factsheet-final-july-2020.pdf>

## ❖ Flowchart for Managing PCBs in School Buildings

[https://www.epa.gov/sites/production/files/2020-06/documents/manage-pcb-in-schools\\_111518.pdf](https://www.epa.gov/sites/production/files/2020-06/documents/manage-pcb-in-schools_111518.pdf)

## ❖ Spill Cleanup Policy Guidance (40 CFR Part 761 Subpart G)

An enforcement policy that applies to spills less than 72 hours

<https://www.ecfr.gov/cgi-bin/text-idx?SID=8d62492eb8cb4323c6fbed2d75d3f5b5&mc=true&node=pt40.34.761&rgn=div5>

## HOW YOU SAMPLE MATTERS

The cleanup rules are based on “as-found” concentrations of PCBs. **That means samples must be collected before the material is disturbed.** Stockpiles may be sampled if they were already in place at the time of site investigation or characterization.

## REQUIREMENTS FOR THE SELF-IMPLEMENTING CLEANUP OPTION

There are very specific requirements for site characterization sampling:



3-meter sampling grid



Sample size and procedure  
(\$761.286)



Specific laboratory methods (extraction methods) (Part 761, Subparts N and O)



Number of samples  
(\$761.283)

Any deviation from the procedures of self-implementing cleanup under 761.61(a) requires approval from EPA under 761.61(c). If the characterization deviates from the regulations, the self-implementing cleanup and disposal option is not applicable

## QUESTIONS? CALL THE EPA.



Call the EPA for questions prior to conducting assessments that may involve PCB remediation waste.



Contact your EPA Regional PCB Coordinator early – as soon as you think you might have or know you have PCBs on your site. You can find contact information for your EPA Regional PCB Coordinator at:



[www.epa.gov/pcbs/program-contacts](http://www.epa.gov/pcbs/program-contacts)

## FOR MORE INFORMATION

Visit the following websites:

<https://www.epa.gov/pcbs>

PCB Facility Approval Streamlining Toolbox (PCB FAST)

<https://www.epa.gov/pcbs/pcb-facility-approval-streamlining-toolbox-fast-streamlining-cleanup-approval-process>

EPA provides checklists to help with the notification (for self-implementing cleanups) and the cleanup application (for risk-based cleanups).



# Polychlorinated Biphenyls (PCBs)

## GUIDE FOR ENVIRONMENTAL PROFESSIONALS



December 2019

(This is a generalized depiction, see 40 CFR Part 761 for full detail.)



# DO YOU HAVE PCB REMEDIATION WASTE AT YOUR SITE?


Even if the spilled material is <50 ppm, it may still be regulated as PCB remediation waste.

## 761.61 (a) Self-Implementing Cleanup

- Must notify the EPA
- Specific sampling requirements
- Can send PCB remediation waste <50 ppm to Subtitle D landfill

## 761.61 (b) Performance Based Disposal

- Not required to notify the EPA
- Must remove all waste with PCB levels above 1 ppm
- Must send to an approved TSCA facility (PCB landfill or incinerator) or decontaminate according to 761.79.



**PCB REMEDIATION WASTE**

There are 3 cleanup options, each with specific sampling and disposal requirements.

**NOT PCB REMEDIATION WASTE**



- No federal cleanup or disposal obligations under TSCA\*\*
- Check your state environmental agency for state requirements

**For any questions, call the EPA.**

\* If the spill was between January 1978 and July 1979, then see 40 CFR §761.3 or call the EPA.

\*\* In situations of unreasonable risk, the EPA may require cleanup of pre-1978 releases. The disposal requirements of §761.61 apply in all cases (see 40 CFR §761.50(b)(3)).









## Coordinated Approval 40 CFR § 761.77

# News

- *EPA and FDEP have a PCB Memorandum of Agreement (MOA).*
- *This is the first PCB MOA in Region 4.*
- *MOA specifies that FDEP will be pursuing the PCB Cleanup and will consult with EPA.*
- *MOA does not apply in all situations. Class of application is designated.*



# R4 PCB Team

## Region 4 Contacts

Terri Crosby-Vega (R4 PCB Coordinator)

*Edmond Burks*

*Peter Johnson*

*Jan Martin*

*Barbara Alfano*

*(PCB and Sustainability Section Chief)*



# Region 4 PCB Coordinator

**Terri Crosby-Vega**

US EPA Region 4

Land, Chemicals and Redevelopment Division

[crosby-vega.terri@epa.gov](mailto:crosby-vega.terri@epa.gov)

404-562-8497

